

MANUAL PLATO

Home

Summary

Tap to select/de-select a category.

Swipe north to negate/un-negate a category.

Swipe south from the inside to the outside of the bar to grow it.

Swipe north from the outside to the inside of the bar to shrink it.

Swipe west/east to go to the next/previous page.

Shelf

Swipe west/east to go to the next/previous page.

Tap on a book entry to open it.


Bottom bar

Hold the next/previous page icon to go the last/first page.

Reader

Viewer

The screen is divided into seven regions:



Gestures by region:

LE (Left Ear):

Normal Mode:

Tap: previous page.

Hold: previous chapter.

Search Mode:

Tap: previous results page.

Hold: first results page.

MB (Middle Band):

Tap: toggle the top and bottom bars.

Hold: perform a full screen refresh.

RE (Right Ear):

Normal Mode:

Tap: next page.

Hold: next chapter.

Search Mode:

Tap: next results page.

Hold: last results page.

TL (Top Left Corner):

Tap: previous location.

Hold: previous bookmark.

TR (Top Right Corner):

Tap: toggle bookmark.

Hold: next bookmark.

BL (Bottom Left Corner):

Tap: table of contents in normal mode, previous page in search mode.

Hold: guess the frontlight if there's more than two frontlight presets defined, toggle the frontlight otherwise.

BR (Bottom Right Corner):

Tap: go to page in normal mode, next page in search mode.

Hold: invert colors.

Swipe west/east to go to the next/previous page.

Bottom bar

Hold the next/previous page icon to go the next/previous chapter.

Home & Reader

Menus

You can select a menu entry *without closing the menu* by holding it.

Top bar

The frontlight can be toggled by holding the frontlight icon.

Bottom bar

Tap the page indicator to go a specific page.

Keyboard

The *ALT* and *SHIFT* keys can be locked by tapping them twice.

The *CMB* (combine) key can be used to enter special characters, e.g.: CMB o e produces œ.

A hold on the delete or motion keys will act on words instead of characters.

Annex

Combination Sequences

o e	œ	a `	à	u "	ú	]]	]]
O e	Œ	e `	è	o "	ó	+ -	±
a e	æ	i `	ì	U "	Ú	- :	÷
A E	Æ	o `	ò	O "	Ó	< =	≤
c ,	ç	u `	ù	z .	ž	> =	≥
C ,	Ç	A `	À	Z .	Ž	= /	≠
a ;	ą	E `	È	t h	þ	- ,	¬
e ;	ę	I `	Ì	T h	Þ	~ ~	≈
A ;	Ą	O `	Ò	a o	å	< <	«
E ;	Ę	U `	Ù	A o	Å	> >	»
a ~	ã	a ^	â	l /	ł	1 2	½
o ~	õ	e ^	ê	d /	ď	1 3	⅓
n ~	ñ	i ^	î	o /	ø	2 3	⅔

A ~	Ã	o ^	ô	L /	Ł	1 4	¼
O ~	Õ	u ^	û	D /	Ð	3 4	¾
N ~	Ñ	w ^	ŵ	O /	Ø	1 5	⅕
a '	á	y ^	ÿ	m u	μ	2 5	⅖
e '	é	A ^	Â	l -	£	3 5	⅗
i '	í	E ^	Ê	p p	¶	4 5	⅘
o '	ó	I ^	Î	s o	§	1 6	⅙
u '	ú	O ^	Ï	-	†	5 6	⅚
y '	ý	U ^	Û	=	‡	1 8	⅛
z '	z	W ^	Ŵ	s s	ß	3 8	⅜
s '	š	Y ^	Ŷ	S s	ß	5 8	⅝
c '	č	a :	ä	o _	º	7 8	⅞
n '	ň	e :	ë	a _	ª	# f	ℓ
A '	Á	i :	ï	o o	°	# n	℥
E '	É	o :	ö	! !	¡	# s	℥
I '	Í	u :	ü	? ?	¿	% o	‰
O '	Ó	y :	ÿ	. -	·	e =	€
U '	Ú	A :	Ä	. =	•	o r	®
Y '	Ý	E :	Ë	. >	>	o c	©
Z '	Ž	I :	İ	. <	<	o p	©
S '	Š	O :	Ö	' 1	'	t m	™
C '	Č	U :	Ü	' 2	"		
N '	Ň	Y :	Ÿ	[[	[[		